

## Pioneer DVD/CD Writers & Supported DVD-Writable Media Overview

DVD-writable Media Table & writing Support by Pioneer DVD/CD Writers

>> DVD-R media table

DVD-R Type	for 1X		for 4X			for 8X				
	1X	2X	1X	2X	4X	1X	2X	4X	6X	8X
Writing speed	1X	2X	1X	2X	4X	1X	2X	4X	6X	8X
Pioneer's writer										
DVR-A03	OK	OK*1	OK	OK*2	X	OK	OK*2	X	X	X
DVR-A04/DVR-104	OK	OK*1	OK	OK*2	X	OK	OK*2	X	X	X
DVR-A05/DVR-105	OK	OK*1	OK	OK	OK	OK	OK	OK	X	X
DVR-A06/DVR-106	OK	OK*1	OK	OK	OK	OK	OK	OK	X	X
DVR-S606	OK	OK*1	OK	OK	OK	OK	OK	OK	X	X
DVR-A07U *1 DVR-A07XLA DVR-A07XLB DVR-107	OK	OK*1	OK	OK	OK	OK	OK	OK	OK*1	OK*1
DVR-SK12D	OK	OK*1	OK	OK	X	OK	OK	X	X	X

\*1: Please be kind to download updated firmware from the Pioneer firmware download page on the web.

OK : Fully supported

OK\*1 : Writable with supported media only

OK\*2 : Writable with the latest firmware

X : Not supported. Writing action does not take place